

Table of Contents

Vertical Slice Test Stand (VST) Instructions.....	1
Configure VST RCE WIB.....	2
Configure RCE.....	3
Take a Run.....	4

Vertical Slice Test Stand (VST) Instructions

Configure VST RCE WIB

- `ssh np04daq@np04-srv-012`
- `cd /nfs/sw/wib/WIBSoftwareTrunk`
- `source env.sh`
- `cd scripts`
- `BUTool.exe -X setup.script # use timing system and RCE # right now, uncomment one of the include FEMB options in the script to pick a FEMB configuration`
- `./dump_vst_wib_rce.sh # diagnostics for VST RCE WIB (See WIBTroubleshoot)`

[Link to more detailed WIB instructions - WIBBasicOp.](#)

Configure RCE

[Link to more detailed RCE instructions - RCEBasicOp](#)

Take a Run

- ssh np04daq@np04-srv-010
- RC
- Take control
- Turn on VST, cob2_rce7 and cob2_rce8. Turn off all other RCEs.
- Turn on reasonable Event Builders and Data Loggers.
- BOOT, CONFIGURE, START ... STOP.

Link to more detailed run control instructions - PdspRunControl.

-- DavidGeoffreySavage - 2018-02-23

This topic: CENF > Np04VstOperation

Topic revision: r2 - 2018-02-23 - DavidGeoffreySavage



Copyright &© 2008-2021 by the contributing authors. All material on this collaboration platform is the property of the contributing authors.

or Ideas, requests, problems regarding TWiki? use Discourse or Send feedback