

-- Main.pyduval - 27 Jul 2007

BER (or GOL) test is used in the same way as the CONNECTIVITY test except that you use GOL instead CONNECTIVITY in the test main panel before starting the test. So refer to the CONNECTIVITY HOWTO page L0MuonHowToConnectivity.

In the result column you see the number of errors that have been counted during the last executed test.

---

This topic: LHCb > L0MuonHowToBER

Topic revision: r2 - 2007-10-10 - PierreYvesDuval



Copyright &© 2008-2020 by the contributing authors. All material on this collaboration platform is the property of the contributing authors.

Ideas, requests, problems regarding TWiki? Send feedback