

0x1: Error during mtrx init

1. Retry the transition
2. If the error is not corrected contact experts

0x2: Error during sca configuration

1. Retry the transition
2. If the error is not corrected contact experts

0x3: Error during Locx2 reset

1. Retry the transition
2. If the error is not corrected contact experts

0x4: Error during MTx reset

1. Retry the transition
2. If the error is not corrected contact experts

0x5: Error during MTx configuration

1. Retry the transition
2. If the error is not corrected contact experts

0x6: Error during Locx2 configuration

1. Retry the transition
2. If the error is not corrected contact experts

0x7: Error during ADC configuration

1. Retry the transition
2. If the error is not corrected contact experts

0x8: Error during delay write of fiber

1. Retry the transition
2. If the error is not corrected contact experts

0x9: Error during MDAQ write

1. Retry the transition
2. If the error is not corrected contact experts

0x10: Error sca id don't correspond

1. OpcUaLarLtdbServer configuration file is not correct
2. Contactexpert to regenerate it

0x11: Error during power on

1. Retry the transition
2. If the error is not corrected contact experts

0x12: Error during power off

1. Retry the transition
2. If the error is not corrected contact experts

0x13: Links not good

- If all links bad: Check Latome configuration/TTC
- If some links are bad
 - ◆ If there was a power cycle: it's needed to redo the locx2scan
 - ◆ If not contact experts

0x14: Error during configuration of Gbtx

- Contact experts

-- EtienneMarieFortin - 2020-04-10

This topic: Main > OpcUaLarLtdbServerTroubleshooter

Topic revision: r5 - 2021-04-20 - FlorentBernon



Copyright &© 2008-2021 by the contributing authors. All material on this collaboration platform is the property of the contributing authors.

or Ideas, requests, problems regarding TWiki? use Discourse or Send feedback